

DC INVERTER AIR TO WATER HEAT PUMP

DEFROSTING SYSTEM

INTRODUCTION
GUIDELINE
TROUBLE SHOOTING



Introduction

This document introduces defrosting program and provides suggestions on how to reset the parameters to achieve optimized defrosting system, and general trouble shooting guide.

1. What is defrosting?

When an **Air to Water Heat Pump** working in cold climate for house or sanitary hot water heating, the water vapor in the air can be cooled down to frost when it flows through the air heat exchanger (Aluminum Finned Tube Heat Exchanger).

The frost accumulates on the surface of the fins of air heat exchanger and may turn into ice which eventually blocked air passage. A process of defrosting will be carried out automatically by heat pump, or manually by technician.

Defrosting is a process of cooling to indoor buffer tank/house and heating to outdoor air heat exchanger for melting the frost/ice. When the frost/ice was removed, heat pump will back to normal working.


Copyright by General Energy Co., Ltd.
info@generalenergy.cn

2. Defrosting process

2.1 Action components list:

No.	Name of Component	Socket No. on PCB	Reading code
1	Compressor	CN501,502,503	
2	4-way valve	CN39	
3	Fan motor	CN27,33	
4	Water pump	CN14	
5	Controller PCB		
6	Ambient air temp sensor	socket PO on PCB	d08(refer to 5.2)
7	Coil temperature sensor	socket PG on PCB	d09(refer to 5.2)
8	Electrical ice melting cable	CN38	


2.1.1 Refrigeration System Diagram:



2.1.2 Find Ambient air temperature sensor and Coil temperature sensor



(Amb. Air temp sensor, Plastic seal)



(Coil temp sensor, Copper seal)

2.2 Starting a defrosting process:

- Defrosting will be started when **all 3 Enter-conditions are ready**. If one of them is not ready, heat pump **will not** start defrost.

➤ **Enter Condition #1:**

Compressor has cumulatively operated for ** minutes.

(** is refer to the setting time of Parameter P15: Defrost interval, refer to 5.1)

And compressor has continuously operated for 5 minutes.

Remarks:

- If Parameter P12 (the method of defrosting) was set 1 (1:SMART), the compressor accumulative operation time will be decided by the defrost program automatically, it doesn't follow the time setting on Parameter P15, and it follows the previous defrost time to decide the current defrost interval time automatically. It means that **the defrost interval cannot controlled by technician**.

- If Parameter P12 was set 0 (0:AUTO), the accumulative operation time will follow the time setting on Parameter P15.

- If the compressor has not cumulatively operated for the time of Parameter P15, heat pump **will not** start the defrosting process.

➤ **Enter Condition #2:**


If actual measured Coil temperature (d09) is lower than **°C for at least 5 minutes.

(** is refer to the setting temperature of Parameter P13, refer to 5.1)

➤ **Enter Condition #3:**

If ambient air temperature (d08) – Coil temperature (d09) > 5°C


- **Action sequence of entering the defrost process:**

- ① Compressor operating frequency drops down to the lowest for 35 seconds;
- ② 4-way valve reverses (with refrigeration pressure);
- ③ Fan motor stops in 5 seconds;
- ④ Compressor operating frequency goes up to the highest;
- ⑤ Water pump keep working;
- ⑥ DHW magnetic 3-way valve (if any) has no action;
- ⑦ Electric heater (if any) keeps working if water outlet temperature is less than 65°C;
- ⑧ The defrosting icon  displayed on LCD controller panel.

2.3 Conditions of exiting defrosting process:

- Defrosting will be terminated as **one of** the below conditions is ready.
 - **Exit Condition #1:**
When Coil temperature (d09) is higher than **°C.
(** is refer to the Parameter P14: Set coil temp. to exit defrosting, refer to 5.1)
 - **Exit Condition #2:**
Actual defrosting time > ** minutes.
(** is refer to the Parameter P16: Defrosting time, refer to 5.1)









No matter which of the Exit-conditions is ready, defrosting will be terminated.

- **Action sequence of exiting the defrost process:**
 - ① Compressor operating frequency drops down to the lowest for 45 seconds;
 - ② Fan motor starts at the same time;
 - ③ 4-way valve reverses back;
 - ④ defrost process will be terminated in 5 seconds;
 - ⑤ Compressor return to normal working frequency;
 - ⑥ The program starts another counting period of defrost interval;
 - ⑦ The defrosting icon  disappeared.

Copyright by General Energy Co., Ltd.
info@generalenergy.cn

3. Controller parameters setting

3.1 Access to setting of parameters on LCD controller

- ① Unlock the keyboard by keep touching on both  and  for 3 seconds;
- ② Enter parameter setting status, touch on  or  to browse parameter P1 to P21;
- ③ Select a parameter by touch on  and the value of parameter will be flashing;
- ④ Adjust by  or , wait for 2 seconds, auto saved.
- ⑤ Finally touch on  to quit the setting;

3.2 Parameter P12: The methods of defrosting

Setting range: **0 (SMART)** or **1 (AUTO)**.

Update Notice:

Due to incorrect translation in the past, we had updated the description on method of defrost:

Old description:	AUTO (0)	MANUAL (1)
Since January 2020, it is updated and change to below new description ↓		
New description:	SMART (0)	AUTO (1)

- Difference between **SMART** and **AUTO**:

SMART defrosting is **not following** the setting of Parameter 15 (defrost interval).

(Under SMART defrosting mode, the program will decide the defrost interval automatically according to the situation of previous defrosting record, in another word, defrost interval cannot be controlled and Parameter P15 is not valid.)

AUTO defrosting is **following** the setting of Parameter 15.

Tips:

1 (AUTO) defrosting is recommended.

3.3 Parameter P13: Set coil temp. to enter defrost

If coil temperature (d09) ≤ the set temperature P13, defrost **Enter-condition #2** is ready.

(At this moment, if both Enter condition #1 and #3 are ready, defrosting process will be started. Otherwise defrosting process will not be started.)

Setting Range:	-15°C<-----↓----->+2°C
Default Setting:	-4°C
Enter defrost timing:	Late<----->Early

Tips:

If the heat pump enters defrosting too late (or too early), please increase (or decrease) this setting degree by degree as: -3°C, -2°C, -1°C and etc.

3.4 Parameter P14: Set coil temp. to exit defrost

If coil temperature (d09) \geq the set temperature P14, defrost **Exit-condition #1** is ready, regardless Parameter P16 (Defrost time), defrosting will be terminated.


Setting Range:	+8°C<-----↓----->+20°C
Default Setting:	15°C
Exit defrost timing:	Early<----->Late

Tips:

If the heat pump exits defrosting too late (or too early), please increase (or decrease) this setting degree by degree as: 15°C, 14°C, 13°C and etc.

3.5 Parameter P15: Defrost interval

It is a time lag between two defrosting process.



It is also an accumulated operation time of compressor related to **Enter Condition #1**.

Setting Range:	25minutes<-----↓----->70minutes
Default Setting:	40minutes
Defrost frequency:	Frequently<----->Rarely

When a defrosting process ended, the program starts to count down the accumulated operation time again.

Tips:

If the heat pump doesn't defrost in time (or too many times), please decrease (or increase) this setting minute by minute as: 40mins, 35mins, 30mins, 25mins and etc.

3.6 Parameter P16: Defrost time

It is a time period for defrosting process.

Setting Range:	2minutes<-----↓----->20minutes
Default Setting:	12minutes
Defrost time:	Short<----->Long

If time is up, regardless Parameter P14 (Set coil temp. to exit defrost), defrosting will be terminated.

Short defrost time leads to that the frost cannot be cleaned efficiently.

Long defrost time leads to waste of energy, or high-pressure protection on heat pump system.

Tips:



Observe and record the actual situation of each defrosting cycle.
According to the record, set a proper defrosting time on Parameter P16.

3.7 Manual defrosting

- **MANUAL** defrosting: A third method of defrost.

This is the emergency method of defrosting process.
In case the heat pump is not defrosting automatically.

Follow below steps to active **MANUAL** defrosting process:

- ① Heat pump is running on heating mode;
- ② Unlock the keyboard, keep touch on  for 3 seconds;
- ③ The defrosting process starts and  (defrost icon) displayed on LCD screen;

Remark:

If the defrost icon disappeared in 10 seconds, it means that the actual coil temperature is higher than the setting temperature of parameter P14 (Set coil temp. to exit defrost). The program will terminate the defrosting process immediately.

4. Trouble shooting

Here are some possible troubles that happened to the air to water heat pump, just for reference.

4.1 Ice blocked the whole bottom pan



Description:

On the bottom pan of heat pump, the drain hole was jammed, condensation water cannot be drained out in time, so it would become ice during cold climate days.

Possible Solutions:

- 1) Melt the ice with boiled hot water.
- 2) Clean the bottom pan and dredge the drain holes.
- 3) If electric ice melting cable was burnt, replace it with a new one.
- 4) If electric ice melting cable was not powerful enough, add one more cable.
- 5) If no output signal from PCB to electric ice melting cable (CN38), replace it with a new one.

4.3 Part of the air heat exchanger frozen



Description:

Frost was not evenly covered on the whole air heat exchanger, only part of the air heat exchanger was frozen.

Possible Solutions:

- 1) Move the coil temperature sensor to a proper position.
- 2) Start manual defrost, refer to 3.7.
- 3) Reset parameters of defrosting (P14 and P16) and enable a longer time defrosting process.

4.4 Air heat exchanger was fully frozen



Description:

Heat pump does not start defrosting and the air heat exchanger was fully frosted.

Possible Solutions:

- 1) Set Parameter 12 to 1 (AUTO);
- 2) Set Parameter P15 to 25 minutes for temporary setting;
- 3) Replace the failed coil temperature sensor with a new one;
- 4) Replace the failed ambient air temperature sensor with a new one;
- 5) Replace the failed PCB with a new one.
- 6) Refrigeration system was jammed and need repair;
- 7) Refrigeration system was leak and need repair;
- 8) Four-way (reverse) valve doesn't swift and need repair.

4.5 Defrosting has not completely cleaned



Description:

After defrosting, there is remain frost or ice stay on the air heat exchanger.

Possible solutions:

- 1) The set temperature of Parameter 14 is too low and it has not defrosted clean, but the defrosting process had been terminated. Set a higher temperature on Parameter P14, to improve the effect of defrosting. Observe and record every defrost cycle, reset the setting of P14 according to the record.
- 2) Coil temperature sensor was not installed on a proper position. Change the position of Coil temperature sensor to another row of copper coil where has heavily frosted.

4.6 Short defrost / Defrost frequently



Description:

Defrosting process is short.

Heat pump defrosts frequently.

Possible solutions:

- 1) The air heat exchanger is dirty. Clean the air heat exchanger with cleaner.
- 2) The air flow is not enough. Fan motor is working abnormally or it is smaller size than the required. It is not capable to provide enough air flow and needs to be replaced with a bigger size.
- 3) Lack of refrigerant. There may be refrigerant leakage, repair the heat pump.
- 4) The expansion valve failed. Check the expansion valve, replace with a new one if it is damaged.
- 5) The air heat exchanger is not big enough. Replace with a bigger size one.

4.6 Frosted heavy



Description:

The frost was very heavy on the air heat exchanger.

Possible solutions:

- 1) Heat pump defrosting late. The setting temperature of Parameter P13 “Set coil temp. to enter defrost” is low. Increase the setting temperature of Parameter P13.
- 2) The setting time of Parameter P15 is too long time, heat pump cannot start defrosting process in time. Keep observes on actual defrost situation and set a shorter time setting on P15, in order to make sure defrost interval is proper.
- 3) The Coil temperature sensor is not installed at a proper position. Change the Coil temperature sensor to another row of copper coil where has heavily frosted.

Copyright by General Energy Co., Ltd.
info@generalenergy.cn

4.8 Frosted unevenly



Description:

The frost or ice was formed unevenly on the air heat exchanger. Part of the air heat exchanger has thickly frosted and the other parts has thinly frosted.

Possible solutions:

- 1) The refrigerant was not distributed evenly into the air heat exchanger, some of the rows has big flow volume and some has small flow volume. Contact with manufacturer for an advice.
- 2) The size of air heat exchanger was not properly match with the specification of fan motor. The air flow is not even when the air passes through the air heat exchanger.
- 3) Increase the air flow by using a bigger size of fan motor and blades.

4.9 Low pressure protection occurred during defrosting

Description:

There is low-pressure protection occurred during the defrosting process.

Possible solutions:

- 1) During the defrosting process, there is no delay setting, or delay time is too short for low pressure protection. Contact with manufacturer for an advice.
- 2) Expansion valve was jammed. Replace the expansion valve if necessary.

4.10 High pressure protection occurred during defrosting


Description:

There is high-pressure protection occurred during the defrosting process.


Possible solutions:

- 1) The set temperature of Parameter 14 is too high. The heat pump is late to exits the defrosting process, and then lead to high pressure protection.
- 2) Observe a complete defrost cycle and record the reading of the coil temperature (d09) at the moment of all the frost was cleaned. According to the reading, set Parameter P14 with a proper setting.

4.10 Sensor or PCB damaged



(Amb. Air temp sensor, Plastic seal)



(Coil temp sensor, Copper seal)

Description: Heat pump doesn't defrost

Possible reason:

1) Sensor damaged.

- Find out where the sensors on the heat pump, ambient air temp. sensor and coil temp. sensor.
- Check the displayed temperatures by operates on the temperatures on LCD controller. (Please refer to 5.2 Readings of Operating Status Table) and record them.
- Check the ambient air temperature by temperature probe and infrared thermometer (telemetry) and compare the temperature readings with the records, in order to know if temperature sensor failed.
- Specification of sensor 5K NTC B3470, for detail, please refer to Appendix 5.3









2) Control main PCB damaged. If the sensors are all right, then it may be PCB failed.

Solution: Replace the sensor or the main PCB.

5 Appendix

5.1 Parameter Setting Table






Follow the below steps to access the parameter setting:

- ① Unlock the keyboard, keep touch on both  (Clock/Timer) and  for 3 seconds;
- ② System enters parameter setting status, touch on  or  to browse parameters;
- ③ Select parameter by touch on , and the value of parameter will be flashing;
- ④ Adjust by  or , 2 seconds, auto saved. Finally touch on  to quit the setting.

No.	Name of Parameter	Default (Range)
P1	Setting desired temperature of water tank (DHW)	55°C (20~60)
P2	Setting desired temperature for AC ROOM HEAT	40°C (15~60)
P3	Setting desired temperature for AC cooling	10°C (5~35)
P4	COMP startup temperature difference for DHW	5°C (3~15)
P5	COMP startup temp. difference for AC (H&C)	3°C (2~15)
P6	Temp. difference for keeping constant water temp.	2 (0~6)
P7	ON/OFF Setting of electric heater at AC (H&C)	0 (0:AUTO/1:OFF)
P8	Desired startup water temp. of electric heater	50°C (30~55)
P9	Electric heater startup delay	30MIN (2~90)
P10	Max. outlet water temp. of AC (H&C)	60°C (25~67)
P11	Lowest HP operating limit of ambient temp.	-30°C (5~35)
P12	Way of defrost	1 (0:SMART/1:AUTO)
P13	Set coil temp. to enter defrost	-4°C (-15~2)
P14	Set coil temp. to exit defrost	15°C (8~20)
P15	Defrost interval	40MIN (25~70)
P16	Defrost time	12 MIN (2~20)
P17	Temp correction for water tank (DHW) temp.	0°C (-5~5)
P18	Temp correction for hot water supply/return	0°C (-5~5)
P19	Control way of water pump in AC ROOM HEAT	0 (0: ON/1: Interval)
P20	Type of heat pump	7 (1/3/5/7)
P21	Manual startup on water pump	0 (0:OFF/1:MANUAL)

5.2 Readings of Operating Status Table

Follow the below steps to access the reading of operating status:

- ① Unlock the keyboard, keep touch on both  and  for 3 seconds;
- ② System enters inquiry to operating status reading;
- ③ Touch on  or  to browse parameter d01 to d19, refer to appendix;
- ④ Finally touch on  to quit the setting;

Code	Explanation
d01	Frequency
d02	Current
d03	Return water temperature
d04	Water tank temperature
d05	How water supply temperature
d06	N/A
d07	Exhaust gas temperature (outdoor unit)
d08	Ambient air temperature
d09	Evaporator coil temperature (outdoor unit)
d10	Compressor return gas temperature
d11	Temperature after expansion valve
d12	The open step of expansion valve
d13	Reserved protection code 1: Frequency limitation on compressor because excessive operating current; 2: Frequency limitation on compressor because excessive exhaust gas temperature; 4: Frequency limitation on compressor because excessive coil temperature at cooling mode; 8: Protection of excessive temperature of IPM module;
d14	Heat pump shut down code 01~55: Shut down because of E01 ~ E55 failure code 61: Shut down because of swift operating mode; 62: Shut down because of water heated to desired temperature; 63: Shut down because of defrost;
d15	The time of a latest shut down
d16	The rotating speed of outdoor fan motor
d71	Target frequency
d18	The open step of expansion valve for EVI system (if it is EVI system)
d19	Temperature of IPM module

5.3 NTC Resistance vs Temperature Table (5K, B=3470±1%)

T(°C)	R(KΩ)	T(°C)	R(KΩ)	T(°C)	R(KΩ)
-30	63.7306	14	7.7643	58	1.5636
-29	60.3223	15	7.4506	59	1.5142
-28	57.1180	16	7.1813	60	1.4856
-27	54.1043	17	6.8658	61	1.4206
-26	51.2686	18	6.5934	62	1.3763
-25	48.5994	19	6.3333	63	1.3336
-24	46.0860	20	6.0850	64	1.2923
-23	43.7182	21	5.8479	65	1.2526
-22	41.4868	22	5.6213	66	1.2142
-21	39.3833	23	5.4048	67	1.1771
-20	37.3992	24	5.1978	68	1.1413
-19	35.5274	25	5.0000	69	1.1008
-18	33.7607	26	4.8108	70	1.0734
-17	32.0927	27	4.6298	71	1.0412
-16	30.5172	28	4.4586	72	1.0100
-15	29.0286	29	4.2909	73	0.9800
-14	27.6216	30	4.1323	74	0.9508
-13	26.2913	31	3.9804	75	0.9228
-12	25.0330	32	3.8349	76	0.8957
-11	23.8424	33	3.6955	77	0.8695
-10	22.7155	34	3.5620	78	0.8441
-9	21.6486	35	3.4340	79	0.8196
-8	20.6380	36	3.3119	80	0.7959
-7	19.6806	37	3.1937	81	0.7730
-6	18.7732	38	3.0809	82	0.7508
-5	17.9129	39	2.9727	83	0.7295
-4	17.0970	40	2.8688	84	0.7086
-3	16.3230	41	2.7692	85	0.6885
-2	15.5886	42	2.6735	86	0.6690
-1	14.8713	43	2.5816	87	0.6502
0	14.2293	44	2.4936	88	0.6320
1	13.6017	45	2.4097	89	0.6144
2	13.0057	46	2.3276	90	0.5973
3	12.4390	47	2.2491	91	0.5808
4	11.9011	48	2.1739	92	0.5647
5	11.3894	49	2.1016	93	0.5492
6	10.9028	50	2.0321	94	0.5342
7	10.4399	51	1.9656	95	0.5196
8	9.9995	52	1.9016	96	0.5088
9	9.5802	53	1.8399	97	0.4919
10	9.1810	54	1.7804	98	0.4786
11	8.8008	55	1.7232	99	0.4650
12	8.4395	56	1.6680	100	0.4533
13	8.0934	57	1.6140		